Gym Floor Cover Care/Cleaning Instructions

Your floor cover is easily cleaned using water and mild dishwashing liquid.

- 1. When using your gym floor cover panels we suggest taping all sections, entrances and exits.
- 2. To clean manually sweep the cover with a dry mop or broom.
- 3. For light cleaning use water only. A spray bottle is an easy, controlled method to apply water.
- 4. For more stubborn marks or dirt add a small amount of mild dishwashing liquid or a diluted cleaner degreaser.
- 5. Scrub with using a soft sponge mop or by placing a cloth over a push broom.
- 6. If using dishwashing liquid rinse thoroughly with water.
- 7. Make sure cover is **<u>completely</u>** dry before rolling and storing.
- 8. Always test a small area with any cleaner you are trying <u>before</u> distributing over entire cover.
- 9. Do not power wash. This could harm the vinyl.
- 10. For black shoe scuff marks and other hard to remove stains try **Regular rubbing (isopropylene) alcohol**
- 11. For stubborn marks our All Natural Citro[™] Cleaner is available.

Not recommended for use on any painted areas

It gently removes shoe polish, paints/ink, lipstick, glue, adhesive and much more.

All Genuine THOR Tarp brand gym floor covers have anti-microbial additive to resist mildew and fungus.

Warning: Clorox is never recommended for use in cleaning any vinyl floor covers. When mixed with other chemicals, it may cause invisible, odorless and deadly fumes.